

---

**PCN Number:** 01/2021  
**Title:** Changed Event Notification Feature on ace 2 cameras  
**Product Family:** ace 2  
**Release date:** January 28, 2021  
**Contact:** Basler Support  
**Type of Change:**  
 Miscellaneous    Firmware    PC Software  
 Product design    Process

## Reason for Change

The Event Notification camera feature allows you to enable camera events and event messages.

With the new firmware, enabling the feature on ace 2 cameras will be identical to all other Basler cameras. This way ace 2 cameras can be integrated without additional efforts to change the existing software for the Event Notification feature.

Please take note of the changed parameter to enable the feature.

## Change Description

### Previous Firmware:

To enable event notification on ace 2 cameras the EventNotification parameter has to be set to **TRUE**.

### New Firmware:

To enable event notifications on ace 2 cameras the EventNotification parameter has to be set to **ON**.

Please refer to our Basler Product Documentation for further information about the feature and Sample Code.

---

**Basler AG**  
**Europe, Middle East, Africa**  
Tel. +49 4102 463 515  
Fax +49 4102 463 599  
support.europe@baslerweb.com  
[www.baslerweb.com](http://www.baslerweb.com)

**The Americas**  
Tel. +1 610 280 0171  
Fax +1 610 280 7608  
support.usa@baslerweb.com

**Asia-Pacific Region**  
Tel. +65 6367 1355  
Fax +65 6367 1255  
support.asia@baslerweb.com

**Affected models and expected first production / shipping date**

Model	Part Number	Revision	Production /shipping Date
a2A1920-160ucBAS	107821	21	February 2021
a2A1920-160ucPRO	107962	11	February 2021
a2A1920-160umBAS	107820	21	February 2021
a2A1920-160umPRO	107961	12	February 2021
a2A1920-51gcBAS	107823	22	February 2021
a2A1920-51gcPRO	107964	14	February 2021
a2A1920-51gmBAS	107822	22	February 2021
a2A1920-51gmPRO	107963	14	February 2021
a2A2590-22gcBAS	108031	13	February 2021
a2A2590-22gcPRO	108132	08	February 2021
a2A2590-22gmBAS	108030	12	February 2021
a2A2590-22gmPRO	108131	08	February 2021
a2A2590-60ucBAS	108029	10	February 2021
a2A2590-60ucPRO	108130	07	February 2021
a2A2590-60umBAS	108028	10	February 2021
a2A2590-60umPRO	108129	07	February 2021
a2A3840-13gcBAS	108017	14	February 2021
a2A3840-13gcPRO	108128	08	February 2021
a2A3840-13gmBAS	108016	13	February 2021
a2A3840-13gmPRO	108127	08	February 2021
a2A3840-45ucBAS	108015	13	February 2021
a2A3840-45ucPRO	108126	07	February 2021
a2A3840-45umBAS	108014	12	February 2021
a2A3840-45umPRO	108125	07	February 2021
a2A4504-18ucBAS	108162	10	February 2021
a2A4504-18ucPRO	108166	10	February 2021
a2A4504-18umBAS	108161	11	February 2021

**Basler AG**  
Europe, Middle East, Africa

Tel. +49 4102 463 515  
Fax +49 4102 463 599

support.europe@baslerweb.com

[www.baslerweb.com](http://www.baslerweb.com)

**The Americas**

Tel. +1 610 280 0171  
Fax +1 610 280 7608

support.usa@baslerweb.com

**Asia-Pacific Region**

Tel. +65 6367 1355  
Fax +65 6367 1255

support.asia@baslerweb.com

# PRODUCT CHANGE NOTIFICATION (PCN)

Model	Part Number	Revision	Production /shipping Date
a2A4504-18umPRO	108165	11	February 2021
a2A4504-5gcBAS	108164	11	February 2021
a2A4504-5gcPRO	108168	11	February 2021
a2A4504-5gmBAS	108163	12	February 2021
a2A4504-5gmPRO	108167	12	February 2021
a2A5320-23ucBAS	108172	10	February 2021
a2A5320-23ucPRO	108176	10	February 2021
a2A5320-23umBAS	108171	11	February 2021
a2A5320-23umPRO	108175	11	February 2021
a2A5320-7gcBAS	108174	11	February 2021
a2A5320-7gcPRO	108178	11	February 2021
a2A5320-7gmBAS	108173	12	February 2021
a2A5320-7gmPRO	108177	12	February 2021
a2A5328-15ucBAS	108116	09	February 2021
a2A5328-15ucPRO	108120	10	February 2021
a2A5328-15umBAS	108115	10	February 2021
a2A5328-15umPRO	108119	11	February 2021
a2A5328-4gcBAS	108118	10	February 2021
a2A5328-4gcPRO	108122	11	February 2021
a2A5328-4gmBAS	108117	11	February 2021
a2A5328-4gmPRO	108121	12	February 2021

Customized cameras based on the same product model might be affected, please contact the Basler Support for clarification.

## Additional Information

Basler may make changes to specifications and product descriptions at any time, without notice. The information in this document is subject to change without notice.

There is no claim to exchange or update the stock or the delivered goods due to the PCN. This applies to customer inventories as well as Basler's own inventory. Also there is no claim to receive the old revision after change.

### Basler AG

#### Europe, Middle East, Africa

Tel. +49 4102 463 515

Fax +49 4102 463 599

support.europe@baslerweb.com

[www.baslerweb.com](http://www.baslerweb.com)

#### The Americas

Tel. +1 610 280 0171

Fax +1 610 280 7608

support.usa@baslerweb.com

#### Asia-Pacific Region

Tel. +65 6367 1355

Fax +65 6367 1255

support.asia@baslerweb.com